



SERVICE SCHEDULE:

Once a Year Major Service

- Change pump oil (10W30)
- Replace orings under valves
- If fitted with a K1 unloader valve, open valve and remove assembly and cap, grease all orings and replace 2 Teflon rings (top of each set)
- Check shaft protruding length. (If shaft protrudes less than 2.6mm, **Replace** unloader valve immediately)
- Check and fix any leaks
- Re-set unloader valve
- Ensure whole machine is working within its parameters

Three Times a Year Minor Service

- Change pump oil (10W30)
- Check and fix any leaks
- Re-set unloader valve
- Ensure whole machine is working within its parameters